

Cleaning recommendation for refrigerated display cases



ATTENTION! Before cleaning, make sure that your unit is **switched off**, food has been removed and that the cleaning agents are chlorine-free, non-corrosive and have been dispensed in accordance with the manufacturer's instructions.



Please observe the accompanying **operating instructions**. Any safety information contained in the operating instructions shall be fully valid in these instructions.
www.ideal-ake.at/en/documents

Area	Video	Cleaning agents	Cleaning aids	Notes	Cleaning	Frequency
Glass/glass enclosure	 1.ideal-ake.at	Glass cleaner	Fine microfibre cloth/ Glass pad with extension	You can lift the glass cover and (depending on the model) tilt the front panel forward or slide it under the glass cover.	Apply cleaning agent and wipe dry with a microfibre cloth. Repeat the process if necessary.	Daily
Shelves	 3.ideal-ake.at	Neutral universal/ glass cleaner	Fine microfibre cloth/ Scratch-free sponge pad	Can be removed by tilting.	Apply cleaning agent, follow manufacturer's instructions, remove coarse contamination with a sponge, then rinse with water.	Daily
Sliding doors	 5.ideal-ake.at	Neutral universal/ glass cleaner	Fine microfibre cloth	Can be removed in the middle position (first at the bottom, then at the top).	Apply cleaning agent, follow manufacturer's instructions, remove coarse contamination with a sponge, then rinse with water.	Daily
LED lighting	 6.ideal-ake.at	Clear water	Fine microfibre cloth	To avoid damaging the LED, apply only light pressure when cleaning.	Clean the LED panels with a damp microfibre cloth.	Daily
Frame/attachments	 7.ideal-ake.at	Neutral universal/ glass cleaner	Scratch-free sponge pad/ coarse microfibre cloth	If these are coated, take particular care to ensure that your cleaning agent does not contain any organic solvents.	Apply cleaning agent, follow manufacturer's instructions, remove coarse contamination with a sponge, then rinse with water.	Daily
Shelves/cups	 8.ideal-ake.at	Neutral universal cleaner	Scratch-free sponge pad/ coarse microfibre cloth	If these are coated, take particular care to ensure that your cleaning agent does not contain any organic solvents.	Apply cleaning agent, follow manufacturer's instructions, remove coarse contamination with a sponge, then rinse with water.	Daily
Swivel walls/ air guides	 9.ideal-ake.at	Neutral universal cleaner	Scratch-free sponge pad/ coarse microfibre cloth	If these are coated, take particular care to ensure that your cleaning agent does not contain any organic solvents.	Apply cleaning agent, follow manufacturer's instructions, remove coarse contamination with a sponge, then rinse with water.	Daily
Tray	 10.ideal-ake.at	Neutral universal cleaner	Scratch-free sponge pad/ coarse microfibre cloth	Fold up the entire evaporator until it locks into place to clean the tray underneath. Do not allow dirt or cleaning water to enter the condensation drain.	Apply cleaning agent, follow manufacturer's instructions, remove coarse contamination with a sponge, then rinse with water.	As required
Evaporator	 12.ideal-ake.at	Clear water	Pressure spray bottle	Make sure that there is no residue between the evaporator fins.	Open the evaporator cover and spray the water between the fins using the pressure spray bottle. Allow the water to drain out and collect it in suitable containers at the drain hose (unless connected to the mains drainage system). Allow the evaporator to dry and wipe off any excess water.	As required
Condenser	 13.ideal-ake.at	Drying	Vacuum cleaner with brush attachment	Be careful not to damage the slats of the condenser. Caution: The fins have sharp edges!	Remove the cover from the condenser. Use a standard vacuum cleaner with a brush attachment and vacuum up any dirt particles.	Weekly